

Software and Hardware Features	GWML-H
<p>Receives and Displays MAYDAY Motion Panic and Manual Alarms from Grace TPASS[®]3 and SuperCELL[®] SC500</p>	YES
<p>Transmits/Receives SEND CALL/EVACUATION Command Grace TPASS[®]3 and SuperCELL[®] SC500</p>	YES*
<p>Transmits/Receives REPORT IN Commands from Grace TPASS[®]3 and SuperCELL[®] SC500</p>	YES**
<p>Transmits and Receives Canned Messages to/from SuperCELL[®] SC500</p>	YES
<p>Diplays Grace Locator Beacon and worker locations. Beacons are overlaid on a user provided .jpeg When the TPASS[®] and/or SuperCELL[®] pass a Locator Beacon, the beacon number is picked up and transmitted to the floorplan image</p>	YES
<p>Capable of sending Text and Email Notifications (Requires Interenet/Network Connection)</p>	YES
<p>Displays Outdoor GPS location as it is transmitted from the GPS model of SuperCELL[®] SC500-H-GPS with</p>	YES