

Features	Supervisor	Lone-Worker
Receives EVACUATION Commands from Grace Monitoring Systems	YES	YES
Receives PAR Check Commands from Grace Monitoring Systems	YES	YES
Monitors Alarms from all Grace devices	YES	YES
Transmits Motion Sensing Panic Alarm	YES	YES
Transmits Manual Panic Alarm	YES	YES
Receives/Transmits Canned Messages from other SC500's and Grace-Watch® Safety Monitor	YES	YES
Capable of Disabling Motion Sensing	YES*	NO
Capable of Selecting Custom Motion Timing (Select in 15 second increments)	YES	NO
Manual Power On/Off	YES	NO
Auto Activation – Power On/Off Requires Powered Cradle.	NO	YES
Transmits Indoor Grace Locator Beacon Position Data	YES	YES
Displays Indoor Grace Locator Beacon Position Data on Grace-Watch® and othe SC500's	YES	YES
Interfaces with customer provided Automotive Telematics for Mobile Lone Worker Solutions	YES	YES
Transmits Outdoor GPS Position Data – Requires Grace-Watch® Monitor for display **	YES	YES
Select Motion Timing when ordering – Changes require USB-IRP Dongle for changes – Sold seperately	NO	YES**
Rechargeable 24 Hour Operation	YES	YES
Recharge Time – 6-8 Hours	YES	YES
Charger Type – 12 VDC, 120VAC, or International – Select when ordering	YES**	YES**
Audio Sound Pressure (dBA) @ 10' when in PANIC/PAR/EVAC	75 dBA	75dBA
Heavy Duty – IP67 Rated	YES	YES
Intrinsically Safe	YES	YES