

## GRACE One (1) Year Warranty

Grace Industries Incorporated, of Fredonia PA 16124 USA, warrants products that it manufactures to be free from defects in workmanship and materials for a period of one (1) year from the original date of purchase. This warranty does not apply to third party products sold by Grace Industries. Grace Industries will repair or replace, at their sole discretion, defective products free of charge. This warranty applies to products that Grace Industries deems defective in its sole discretion due to defects in material or workmanship under normal use and maintenance and where a defect was not caused by accident, misuse or abuse of the product and that no disassembly, repairs or parts replacement were made or attempted by other than Grace Industries' personnel. GRACE INDUSTRIES, INCORPORATED SHALL NOT BE LIABLE FOR ANY DIRECT, INCIDENTAL OR CONSEQUENTIAL LOSS OR DAMAGE ARISING OUT OF THE USE OF THE PRODUCT OR FAILURE OF THE PRODUCT TO OPERATE.

The sole and exclusive remedy under all guarantees or warranties, expressed or implied, is strictly limited to repair or replacement as herein provided. ALL IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO WARRANTIES OF FITNESS AND MERCHANTABILITY, ARE HEREBY LIMITED IN DURATION TO A PERIOD OF ONE (1) YEAR FROM THE DATE OF ORIGINAL PURCHASE. The warranty and liability set forth here are in lieu of all other warranties, expressed or implied, in law or in fact, including warranties of merchantability and fitness for a particular purpose.

Warranty claims process: 1) Obtain a Return Authorization Number from Grace Industries corporate headquarters by calling phone number 724-962-9231, or by email correspondence to sales@graceindustries.com. 2) The product name, serial number, date and proof of purchase must be provided and 3) Return products including Return Authorization Number, prepaid and accompanied by original proof of purchase that states the date and location of purchase to: Grace Industries, Inc., Service Department, 305 Bend Hill Road, Fredonia, PA 16124, USA. Customer is responsible for all shipping costs, return shipping costs, handling, or any other fees associated with a warranty claim.



Glow Baton®  
in Rubber Base

Printed in U.S.A.

GB Glow Flash Strobe UI 1223

# GLOW BATON®

## Multi Use Safety and Marshalling Wand

### Glow Flash Strobe Series




# GRACE INDUSTRIES, INC.

*Solutions for Life Safety*

305 Bend Hill Road, Fredonia, PA 16124  
www.graceindustries.com

## GLOW BATON® Models GB100HD, GB400HD & GB500HD



Glow Baton® is a lightweight, multi-use safety and marshalling wand.

High intensity LEDs, rugged construction, and light weight make this wand ideal for every application where safety and visibility awareness is needed, even in extreme weather conditions.

Add the optional heavy-duty rubber base and Glow Baton® becomes a roadside flare.

Made of heavy-duty materials and construction, Glow Baton® will provide reliable service and safety at the push of a button!

### Recommended Uses

- Traffic Control
- Crowd Control
- Airport Marshaling
- Emergency Signaling
- Military Operations
- Direction Guides
- Event Parking
- Police & Fire
- Roadside Flare
- Duty Patrol
- Crosswalk Guards
- Security Guards

### Specifications

**Brand:** Glow Baton®

**One button operation**

**Material:** Impact resistant polymer materials; Non-slip textured grip with lanyard

**Size:** 16" long x 1.63" dia. ; 9" illuminated tube

**Weight:** 12.7 oz with batteries

**Power:** Two (2) C-cell alkaline batteries

**Run Time:** 72 hours Glow; 144 hours in Flash or Strobe modes

Unscrew end cap to replace batteries.

### Glow, Flash, Strobe Models:

**GB100HD:** One color - Red

**GB400HD:** Two color - Red, Green

**GB500HD:** Three color - Red, Green, Blue

### Glow Baton® Care and Maintenance

To avoid battery leakage, follow these recommendations:

- Never mix battery chemistries/types or brands.
- Do not mix old and new batteries.
- If the Glow Baton® has been dropped or impacted, inspect batteries for damage and replace both batteries if damaged.
- Remove batteries if Glow Baton® will be stored for more than 6 months.
- Do Not leave drained batteries in Glow Baton®; replace batteries immediately if they are depleted or weak.

# **GLOW BATON®** Model GB100HD - Red LEDs

## **User Information**

Press button to turn Glow Baton® **ON**; Press again to turn **OFF**.

1. **GLOW:** Press and release button to turn Glow Baton® **ON** for **GLOW**.
2. **FLASH:** Press and hold button (approx. 3 seconds) until Glow Baton® changes from glow to **FLASH**
3. **STROBE:** Press and hold button (approx. 5 seconds) until Glow Baton® changes from glow, to flash, and then to **STROBE**.

# **GLOW BATON®** Model GB400HD - Red and Green LEDs

## **User Information**

Each button press will index to the next color.

Press button once for **Red**, press again for **Green**, press again to turn **OFF**.

1. **GLOW:** Press and release button to turn Glow Baton® **ON** for **GLOW**.
2. **FLASH:** Press and hold button (approx. 3 seconds) until Glow Baton® changes from glow to **FLASH**
3. **STROBE:** Press and hold button (approx. 5 seconds) until Glow Baton® changes from glow, to flash, and then to **STROBE**.

# **GLOW BATON®** Model GB500HD - Red, Green, and Blue LEDs

## **User Information**

Each button press will index to the next color.

Press button once for **Red**, press again for **Green**, press again for **Blue**, press again to turn **OFF**.

1. **GLOW:** Press and release button to turn Glow Baton® **ON** for **GLOW**.
2. **FLASH:** Press and hold button (approx. 3 seconds) until Glow Baton® changes from glow to **FLASH**
3. **STROBE:** Press and hold button (approx. 5 seconds) until Glow Baton® changes from glow, to flash, and then to **STROBE**.